

Belt-Way Conveyor Belt Scales for Every Application

The **Belt-Way Remote Start / Stop Station** automates Truck, Barge or Rail Car Load-Out.
2 Channel I/O Board Required

Easy Setup of **Belt-Way** Scale Control for Automated Load-Out:



1. **Press F5** on the Keypad to enter 8 different Load-Out amounts.

Note – A CUTOFF amount may also be entered to allow for material between cutoff point (i.e. hopper gate or feed belt) and scale.

Operating Instructions for the **Belt-Way** Remote Start / Stop Station:

2. **SELECT DESIRED LOAD-OUT AMOUNT** using the 8 position Selector Switch (lower right)
3. **PRESS ENTER LOAD BUTTON** (lower left): The selected Load-Out amount appears on line one of the Scale Control Display
4. **PRESS CLEAR “READY” BUTTON** (upper left): The “READY” light will turn on and scale weight will appear as .000 on line two of the Scale Control Display
5. **PRESS START “RUN” BUTTON** (upper right): The “RUN” light will turn on and material flow begins.



When the scale weight reaches the Load-Out amount (minus the CUTOFF weight), the scale material flow stops automatically.

You may stop the conveyor, or pre-feed device at any time during Load-Out by pressing the STOP button (middle right). Load-Out is resumed by pressing the START “RUN” button (upper right). Load-Out may be aborted entirely by clearing LOAD WT on the Scale Control



PRESS PRINT (middle left) on Remote Start / Stop Station to print a ticket using the **Belt-Way Panel Mount Printer**.